

Extension handle

Code	Applicable
EH100-S	ABN53C~100C
EH250-S	ABN200C~250C
EU70-U	ABN400C
EU80U	ABN800C



EH250-S



AX-E3127

Auxiliary

Code	Applicable	Description
AX-E3127	ABN53C~250C	Right Hand 1NO/1NC
AX-E3128	ABN53C~250C	Left Hand 1NO/1NC
AX-E3129	ABN400C~800C	Right Hand 1NO/1NC
AX-E3130	ABN400C~800C	Left Hand 1NO/1NC



AL-E3131

Alarm

Code	Applicable	Description
AL-E3131	ABN53C~250C	Right Hand 1NO/1NC
AL-E3132	ABN53C~250C	Left Hand 1NO/1NC
AL-E3133	ABN400C~800C	Right Hand 1NO/1NC
AL-E3134	ABN400C~800C	Left Hand 1NO/1NC

Shunt Trip

Code	Applicable	Description
SHT-E3135	ABN53C~250C	12V AC
SHT-E3136	ABN53C~250C	24V AC
SHT-E3137	ABN53C~250C	48V AC
SHT-E3138	ABN53C~250C	100 - 130V AC
SHT-E3139	ABN53C~250C	200 - 250V AC
SHT-E3140	ABN53C~250C	380 - 450V AC
SHT-E3141	ABN53C~250C	440 - 500V AC



SHT-E3140