


XB2-BZ009



XB2-BZ101



XB2-BZ105



XB2-BW071



ND16-22F



Push Button contact blocks

Code	Description	Auxiliary Contacts
XB2-BZ101	Support base + contact block	1NO
XB2-BZ102	Support base + contact block	1NC
XB2-BZ103	Support base + contact block	2NO
XB2-BZ104	Support base + contact block	2NC
XB2-BZ105	Support base + contact block	1NC + 1NO
XB2-BE101	Contact block	NO
XB2-BE102	Contact block	NC
XB2-BZ009	Push button support base only	

Contact Block Illuminator

Code	Voltage	Action	Auxiliary Contacts
XB2-BV60	400V	Max Direct	N/A
XB2-BV7	230V	Max Resistor	N/A
XB2-BW061	400V	Max Direct	1xNO
XB2-BW062	400V	Max Direct	1xNC
XB2-BW071	230V	Max Resistor	1xNO
XB2-BW072	230V	Max Resistor	1xNC

Buzzer

Code	Voltage	Description
ND16-22F 110V	110VAC	Interrupted type
ND16-22F 230V	230VAC	Interrupted type
ND16-22L 110V	110VAC	Continuous Type
ND16-22L 230V	230VAC	Continuous Type